

REVISION	CHANGE	APPROVED	DATE
1	Published release	JTS	27/11/2025




Airmaster Propellers Ltd  
20 Haszard Rd, Massey,  
Auckland 0614, NZ  
Phone: (+64) 9 833 1794  
E-mail: [support@propellor.com](mailto:support@propellor.com)  
Web: [www.propellor.com](http://www.propellor.com)

**ASI-4-8-4**

# **SENSOR-BRUSH INSTALLATION (UL-POWER)**

## **PROCEDURE**



### **SUBJECT:**

Sensor-Brush Installation

#### **ASSEMBLY NO:**

AR-Uxxx

#### **APPLICABILITY:**

All propeller models used with a  
UL-Power engine

## 1. TOPIC

### 1.1 Introduction

This document covers the procedure for mounting an Airmaster sensor-brush assembly to a UL-Power engine.

Airmaster offer a range of mounting bracket solutions designed for UL-Power engines, accommodating engine flanges that feature either of the following propeller bolt patterns:

- Standard Rotax bolt pattern (4-inch PCD)
- SAE-1 bolt pattern (4.375-inch PCD)
- SAE-2 bolt pattern (4.75-inch).

These brackets are available in four lengths:

- 35mm
- 55mm (standard)
- 90mm
- 110mm

The installation procedure is consistent across all variants.

It is recommended that installers mount the hub to the engine flange beforehand and attach the sensor-brush assembly to its extension bracket before proceeding.

### 1.2 Prerequisites

- Mount hub to the engine flange in accordance with the applicable installation procedure.

**① Note**

*The illustrations in this document do not show the hub mounted to the engine flange. This is to illustrate the sensor-brush mounting components more clearly as they would otherwise be obstructed from view.*

- Inspect brushes for signs of damage or defect. Check brushes travel smoothly and evenly through the brush holder when they are compressed.
- Attach sensor-brush block (A0120) to UL brush head extension bracket (P0872-x) in accordance with procedure **ASI-4-8-1**.

**① Note**


*Generally, new propellers are supplied with the sensor-brush assembly pre-fitted to its mounting bracket, but in some cases, this must be performed by the installer.*

## 2. MATERIAL REQUIREMENTS

### 2.1 Parts

ITEM	QTY	PART NO.	DESCRIPTION	IMAGE
1.	1	A0120	Airmaster Sensor-Brush Assembly	
2.	1	AR-Uxxx	Airmaster UL Standard Slipring Assembly	

### 2.2 Tooling

ITEM	QTY	DESCRIPTION	IMAGE
1.	1	5mm Hex Key	
2.	1	Torque Screwdriver (5mm Hex Bit) [8-10Nm]	
3.	As required	Digital Multimeter (with probes)	

### 2.3 Consumables

ITEM	QTY	DESCRIPTION	IMAGE
1.	As required	Cleaning Agent (Non-Corrosive) (e.g. Loctite® SF 7063, Methylated Spirits)	
2.	As required	Paper Towels, Clean Cloth (or similar)	
3.	As required	Torque-Seal	
4.	As required	Piece of Card	

### 2.4 Paperwork

ITEM	QTY	CODE	DESCRIPTION
1.	1	AR-Uxxx	Airmaster UL Slipring Assembly Drawing & BoM

### 3. PROCEDURE

#### 3.1 Mount Sensor-Brush Bracket (UL-Power)


##### PROCEDURE

###### Step 1 Remove Thrust Bearing Mount Screws

- Remove (2) right-most (facing engine) M6 cap screws retaining the thrust bearing mount to the front of the UL-Power engine.

**Note** Store in case needed for future use.

**Attention** 5mm Hex key




###### Step 2 Clean Mounting Holes

- Clean (2) holes and surface surrounding the area where bolts were removed.

**Caution**


Any paint or debris left remaining in this area may lead to misalignment of the brushes and sliprings.

**Attention** Cleaning agent, Paper towel



###### Step 3 Assemble Mounting Bracket

- Loosely fit (1) M6 x 30mm cap screw (P0880) and Nord-Lock® washer pair (P0860) into the brush head mounting bracket (P0870-x).
- Slide brush head extension (P0872-x) (with sensor-brush block attached) through the mounting bracket to a rear position.




## Step 4 Mount Sensor-Brush Bracket

- Mount the assembled bracket to the engine's thrust bearing mount with (2) M6 x 45mm cap screws (P0881) and Nord-Lock® washer pairs (P0860).

**Caution**

*The carbon brushes are delicate, and side-loading should be avoided. While the sensor-brush assembly is positioned, use a piece of card to compress the brushes as they slide across the propeller's slippings assembly.*

- Torque cap screws to **10Nm (7.4ft-lbs)**.
- Indicate with torque-seal.




**Attention**

*Torque screwdriver (5mm hex bit), Torque-seal*

## Step 5 Set Sensor-Brush Block Stand-Off

- Slide the brush head extension through the bracket to achieve a gap of approx. **1-2mm (0.08in)** between the brush block and the slippings.
- Check brushes align with centreline of hub.
- Once the brush head position is set correctly, torque the clamping cap screw to **8Nm (5.9ft-lbs)**.
- Indicate with torque-seal.



**Note**

*There is no requirement to lock-wire bolts when Nord-Lock® washers are used.*

**Attention**

*Torque screwdriver (5mm hex bit), Torque-seal*

### 3.2 Check Sensor-Brush Installation


#### PROCEDURE

##### Step 1 Check Sensor-Brush Block Stand-Off

- Check distance from front of brush block to sliprings does not exceed **1-2mm (0.08in)**.

 **Note**

*If this condition is not met, adjust the position of the sensor-brush block in the clamping bracket.*




##### Step 2 Check Sensor-Brush Alignment

- Check carbon brushes align centrally with their respective sliprings and do not overlap.

 **Note**

*If this condition is not met, small modifications to the mounting bracket may be required. A round file may be used to elongate the bracket mounting holes to correct brush alignment.*



##### Step 3 Check for Electrical Shorts

- Check there is no electrical continuity between each brush/slipring and the sensor-brush mounting bracket/ground ( $>1k\Omega$ ).

 **Attention** *Digital multimeter (with probes)*

### 3.3 Subsequent Action

Perform the following tasks once this procedure is complete:

- Connect sensor-brush assembly cable to extension loom (A0125-x). This loom is routed through the engine bay and connected to the controller [CN2].