

REVISION	CHANGE	APPROVED	DATE
1	Published release	JTS	28/11/2025

**Airmaster**


Airmaster Propellers Ltd  
20 Haszard Rd, Massey,  
Auckland 0614, NZ

Phone: (+64) 9 833 1794  
E-mail: [support@propellor.com](mailto:support@propellor.com)  
Web: [www.propellor.com](http://www.propellor.com)

**ASI-7-3-4**

# TROUBLESHOOTING OVER-CURRENT ALARM

## PROCEDURE



### **SUBJECT:**

Troubleshooting

**ASSEMBLY NO:**

AP-xxx

**APPLICABILITY:**

All propeller models

# 1. TOPIC

## 1.1 Introduction

This document covers the recommended procedure for troubleshooting an over-current alarm for an Airmaster propeller. An over-current occurs when the electrical load (current) drawn by the propeller's pitch change motor exceeds:

- In AUTO mode: the preset current limit programmed in the controller.
- In MAN mode, the thermal circuit breaker threshold (typically 6.1A).

**① Note** For AC200 hardware versions 4 or lower, the circuit breaker threshold is 3.15A.

### 1.1.1 Symptoms

If the over-current occurs during automatic (AUTO) mode:

- The controller lamp illuminates red in the affected pitch change direction.

If the over-current occurs during manual (MAN) mode:

- The controller's resettable thermal circuit breaker (FS1) may trip.

In either scenario, no automatic (AUTO) operation of the propeller is possible (this is disabled due to the internal current-monitoring function of the controller).

### 1.1.2 Possible Causes

- Mechanical constriction in the pitch change mechanism or blades (e.g. poor lubrication, seized components, or foreign material causing obstruction).
- Electrical short from damaged or exposed electrical hardware.
- Current limit setting programmed into the controller is too low for PC motor type.
- Faulty circuit breaker.
- Failure of the propeller's adjustable pitch limit stops, allowing the pitch change mechanism to drive against the hard stops of the propeller hub.

## 1.2 Prerequisites

Complete the following tasks before proceeding:

- Inspect all electrical looms to the propeller for signs of damage, corrosion, moisture ingress or loose connection (i.e. power supply cable, extension loom, sensor-brush cable, slipring connections).
- With power to the propeller turned off, unplug the connectors at each end of the sensor-brush assembly cable (A0120) and the extension loom (A0125-x). Check all pins are inserted properly into their receptacle and appear in good condition.

**① Note** Refer to control system assembly drawing (AC-xxx).

- Inspect sensor-brush assembly in accordance with procedure **ASI-7-4-1**.

**① Note**

*The expected service life for these brushes is approximately 600 hours with a mini slipring assembly and approximately 300 hours with a standard slipring assembly. Environmental factors also influence service life.*

## 2. MATERIAL REQUIREMENTS

### 2.1 Tooling

ITEM	QTY	DESCRIPTION	IMAGE
1.	1	PH2 Screwdriver	
2.	1	Flathead Screwdriver	
3.	1	Wire Cutter	
4.	1	Airmaster USB-Serial Cable A0117	
5.	1	MS Windows PC	
6.	1	Airmaster User Program (.exe)	
7.	1	Airmaster Diagnostics Program (.exe)	

### 2.2 Paperwork

ITEM	QTY	CODE	DESCRIPTION
1.	1	-	Airmaster Control System Circuit Diagram
2.	1	AC-xxx	Airmaster Control System Assembly Drawing & BoM
3.	1	AH-xxx	Airmaster Hub Assembly Drawing & BoM
4.	1	AR-xxx	Airmaster Slipring Assembly Drawing & BoM


### 3. PROCEDURE

#### 3.1 Check Brush Block Solder Joint

##### PROCEDURE

###### Step 1 Remove Sensor-Brush Assembly

- Remove sensor-brush assembly by either of the following methods, based on which is most convenient:
  - Detach sensor-brush block from mounting bracket via (4) 8-32 UNC cap screws, then carefully slide the block out from between the bracket and slings.
  - Remove mounting bracket from engine first, then detach sensor-brush assembly via (4) 8-32 UNC cap screws.
- Unplug sensor-brush cable connector from extension loom.



###### Caution


Insert a piece of card between the brushes and slings to protect the brushes as the sensor-brush assembly is removed.

###### Note

Standard slings and sensor-brush bracket shown.

###### Attention

9/64" Hex-key (for 8-32 UNC cap screws)  
5mm or 6mm Hex-key (depending on bracket).




###### Step 2 Check Solder Joint Height

- Dry-fit sensor-brush block against mounting bracket.
- Confirm solder joints located on rear circuit board do not contact the bracket (this may create an electrical short).
- Trim solder joints as necessary to prevent contact.



###### Attention

Wire Cutter (as required)




### 3.2 Check Hub Wiring

#### PROCEDURE

##### Step 1 Remove Spinner Cone

- Remove spinner cone from backplate via truss-head screws.

 **Attention** PH2 Screwdriver



##### Step 1 Remove Motor Cap


- Remove any lock-wire retaining motor cap screws.
- Remove motor cap from hub via (6) fillister-head screws.

 **Note**

*Do not remove front support from hub motor cap.*


 **Attention**

*Wire Cutter, Pliers, Flathead screwdriver*



##### Step 2 Check Hub Wiring

- Inspect all wiring inside the hub for damage such as breaks or pinches which may cause an electrical short.




### 3.3 Check for Mechanical Resistance

#### PROCEDURE


##### Step 1 Remove Blades

- Remove blades from hub in accordance with procedure **ASI-7-6**.




##### Step 2 Inspect Hub Bores

- Inspect hub bores for damage.
- Check hub bores are adequately greased in accordance with procedure **ASI-4-5**.




##### Step 3 Inspect Pitch Change Mechanism

- Inspect pitch change mechanism in central area of hub for signs of damage or deformation (i.e. lead screw, rods, beatings, plastic block).
- Check leadscrew is lubricated.
- Check for presence of foreign material



##### Step 4 Inspect Blades

- Check blade retention assemblies are adequately greased in accordance with procedure **ASI-4-5**.
- Inspect blade retention assemblies for signs of damage.
- Rotate deep groove bearing (base of blade) by hand and check for smooth rotation.




### 3.4 Check Pitch Limit Stops

#### PROCEDURE


##### Step 1 Aircraft Setup

- Engine OFF.
- Apply power to the propeller.




##### Step 2 Set Controller to MAN

- Set controller to manual over-ride mode (MAN).




##### Step 1 Check Fine Pitch Stop

- Toggle FINE on manual control switch to drive propeller to fine pitch limit stop (FINE lamp on controller illuminates green).
- Inspect pitch change mechanism inside hub and confirm it has not impacted the fixed hard stop (ceiling of hub).



##### Step 2 Check Coarse Pitch Stop

- Toggle COARSE on manual control switch to drive propeller to coarse pitch limit stop (COARSE lamp on controller illuminates green).
- Inspect pitch change mechanism inside hub and confirm it has not impacted the fixed hard stop (floor of hub).



### 3.5 Check Controller Settings

#### PROCEDURE


##### Step 1 Check Current Limit Parameter

- Connect to controller in User Program and view controller parameters in accordance with procedure **ASI-7-2-1**.
- Navigate to ‘Settings’.
- Check ‘Current Limit (040)’ parameter matches the value shown in the ‘ACx00 Parameters Sheet’, representing current in [mA].

**Note**

The correct current limit value depends on PC motor type (refer to Airmaster if in doubt):

- Maxon 150/231/243 motor = 2500mA
- Faulhaber 196 motor = 4000mA
- AMC Maxon AMC18/24-231 motor = 5000mA
- (AMC) Maxon 326 motor = 5000mA
- Brushless Maxon i30 motor = 5000mA



##### Step 2 Download Log Files

- If applicable, download log files from controller in accordance with procedure **ASI-7-2-4**.
- Send resultant log file (.dat) to Airmaster ([support@propellor.com](mailto:support@propellor.com)) for review and advice.

